



5+


**PACKAGE CONTENTS: 1 FART NINJA, 1 INSTRUCTION SHEET**  
**REQUIRED: 3 X 1.5V "LR44/AG13" BUTTON CELL BATTERIES (INCLUDED)**

## SET UP

1 SLIDE THE SWITCH  
AT THE BACK OF HIS  
HEAD TO ON.




2 HIDE YOUR FART NINJA.  
BUT MAKE SURE NOTHING  
IS BLOCKING THEIR FACE.



SENSOR

3

EACH TIME THEIR  
SENSOR IS TRIGGERED,  
YOUR FART NINJA  
WILL RELEASE A  
THUNDEROUS FART.



Read Operator's Manual

- **WARNING:** This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. In Australia, call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert advice.
- **WARNING -KEEP BATTERIES OUT OF REACH OF CHILDREN**
- Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.

**FOR MORE INFO VISIT**  
**[WWW.FARTNINJAS.COM](http://WWW.FARTNINJAS.COM)**

\* All instruction sheets must be retained since it contains important information.

© 2025 Funrise, inc. All Rights Reserved

**Funrise**