

5+

LAUNCH A  
FART  
ATTACK!

COLLECT THEM ALL !



70597  
EXPLODING  
WIND



70600  
SONIC  
EGG



70589  
STINK  
EYES



70590  
SONIC  
BOOM



70596  
RANCID  
BACKDRAFT



70594  
POISON  
BUBBLER



70593  
STENCH  
BLOSSOM



70595  
GLUTEOUS  
STANK



70598  
HIDDEN  
STENCH



70591  
CREEPING  
STANK



70599  
POWER  
RIPPER



70592  
FLAT YU  
LANCE




PACKAGE CONTENTS: 1 FART NINJA, 1 INSTRUCTION SHEET  
REQUIRED: 3 X 1.5V "LR44/AG13" BUTTON CELL BATTERIES (INCLUDED)

SET UP

1 SLIDE THE SWITCH AT THE BACK OF HIS HEAD TO ON.



2 HIDE YOUR FART NINJA. BUT MAKE SURE NOTHING IS BLOCKING THEIR FACE.




3 EACH TIME THEIR SENSOR IS TRIGGERED, YOUR FART NINJA WILL RELEASE A THUNDEROUS FART.

FREE APP!

INCLUDES A FART MIXER THAT YOU CAN RECORD WITH YOUR FART NINJAS XL AND A FART NINJAS PHOTO BOOTH!

FOR MORE INFO VISIT [WWW.FARTNINJAS.COM](http://WWW.FARTNINJAS.COM)



- WARNING: This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. In Australia, call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert advice.
- WARNING -KEEP BATTERIES OUT OF REACH OF CHILDREN
- Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.

\* All instruction sheets must be retained since it contains important information.

Funrise®



[www.funrise.com](http://www.funrise.com)